


HVLP SUCTION TYPE AIR SPRAY GUN



PARTS LIST

No.	Parts No.	Description	Q'ty	No.	Parts No.	Description	Q'ty
1	1305-01	Air Cap	1	13	1305-13	Air Valve Seat Set	1
2	1305-02A	Fluid Nozzle 1.0 [SS-1305HSPB]	1	1305-13-1	O-Ring	1	
	1305-02B	Fluid Nozzle 1.3	1	14	1305-14	Air Valve Spring	1
	1305-05C	Fluid Nozzle 1.4	1	15	1305-15	Fluid Adj. Guide Set	1
	1305-05D	Fluid Nozzle 1.5	1	16	1305-16A	Fluid Needle 1.0 [SS-1305HSPB]	1
	1305-05E	Fluid Nozzle 1.8	1		1305-16B	Fluid Needle 1.3	1
	1305-05F	Fluid Nozzle 2.0	1		1305-16C	Fluid Needle 1.4	1
	1305-05G	Fluid Nozzle 2.5	1		1305-16D	Fluid Needle 1.5	1
3	1305-03	Needle Packing Set	1		1305-16E	Fluid Needle 1.8	1
4	1305-04	Needle Packing Seat	1		1305-16F	Fluid Needle 2.0	1
5	1305-05	Body Set	1		1305-16G	Fluid Needle 2.5	1
6	1305-06	Fluid Nipple	1	17	1305-17	Needle Spring	1
7	1305-07	Pattern Adj. Set	1	18	1305-18	Fluid Adj. Knob	1
8	1305-08	Air Valve Shaft	1	19	1305-19	Air Inlet Nipple	1
9	1305-09	Packing Holder	1	20	1305-20	Air Adj. Set	1
10	1305-10	O-Ring	1	21	1305-21	Trigger	1
11	1305-11	Gasket	1	22	1305-22	Gasket	2
12	1305-12	Air Valve Seal Set	1	23	1305-23	Trigger Stud	1
	1305-12-1	O-Ring	1	24	1305-24	E-Ring	1