



## AOM SPRAY EQUIPMENT

5005 SANBUSCO DR. NE  
RIO RANCHO, NM 87144  
505-867-1946  
FAX 505-867-1948

### 75-111SS 2 1/2 QT STAINLESS STEEL PRESSURE POT

CAN BE USED WITH ALL ASTURO SPRAY GUNS

#### IDEAL APPLICATIONS:

FOR ALL WATER BASE COATINGS

ADHESIVES

PAINT

PRIMERS

LIQUID DYES

STAINS

CLEAR

ALL SOLVENT BASED PAINTS

MAXIMUM WORKING PRESSURE 50 P.S.I.

FLUID OUTLET 3/8"

AIR OUTLET 1/4"

DIMENSIONS 9" x 9" x 17.5"

#### OPERATION:

Connect hose as shown in diagram.

Fill cup with strained fluid mixed in accordance with manufacturer's recommendations on label of container.

Fasten cover securely.

Set air pressure at oil and water extractor (transformer) to between 35 and 80 P.S.I., depending upon atomization desired.

Set regulator on pressure cup to approximately

5 P.S.I. for enamels: 3 P.S.I. for lacquers.

(Turn knob clockwise to increase pressure:

to reduce pressure, turn knob counter-clockwise. Always release air in cup by momentarily opening air release valve on cover when attempting to reduce pressure)

Open air adjusting valve.

With trigger fully pulled back, make several fast spray strokes against a flat surface. After adjustment of pressure, proper atomization will be indicated by an even distribution of finely divided paint particles.

